


Advances in On-line Instrumentation for Wastewater Process Control

Justin Irving, P.E



NEWEA
WORKING FOR WATER QUALITY

January 27, 2015

Acknowledgements

Sarah Galst, P.E. (Hazen and Sawyer)

Phill Yi, P.E. (Hazen and Sawyer)

Katya Bilyk, P.E. (Hazen and Sawyer)

Presentation Outline

1. Goals/Considerations

**2. Background on
Parameters of Interest
and Measuring
Techniques**

**3. Case Studies Utilizing
Instrumentation and
Models**




Goals/Considerations

Goals of Monitoring in WWTPs

- Better Understanding
- Advanced Warnings of Problems
- *Better Effluent Quality*
- *Reduced Energy Use*
- *Reduced Chemical Consumption*
- **Simplifying Wastewater Treatment**




Courtesy of New York Times



Courtesy of PolicyMed

Considerations (High-Level)

- How can this information be used?
- Are staff resources available to adequately maintain the sensors **and review the data?**
- If cost-savings is a goal, is the overall control strategy going to work?



Considerations (Detailed)

- Can the sensor monitor over the range/accuracy needed?
- How will the location of the sensor impact the measurement
- If a single sensor is “mission-critical”, should there be redundancy (if so, how much)?



Background

Parameters of Interest

Conventional Parameters

- Dissolved Oxygen
- Temperature
- pH/alkalinity
- Oxidation-Reduction Potential
- Total Suspended Solids
- *Flow*

“Advanced” Parameters

- Ammonia
- Nitrate (NO_x-N)
- COD/BOD Surrogates
- Phosphorous

Dissolved Oxygen

- Amperometric Sensor
 - Low capital costs
 - Higher maintenance
 - Less reliable due to consumables
 - Higher **absolute** accuracy
- Optical Sensor
 - Higher capital costs (\$1 – 2K)
 - Lower maintenance
 - More reliable due to ease of maintenance
 - Lower **absolute** accuracy



Courtesy of Hach



Courtesy of InsiteIG

Oxidation Reduction Potential (ORP)

- Measurement of Oxidizing and Reducing Conditions
- Represents State of Process
- Inexpensive, low-maintenance

Biochemical activity	Approximate ORP range
Carbon oxidation (carbonaceous biochemical oxygen demand stabilization)	+50 to +200
Polyphosphate accumulation	+50 to +250
Nitrification	+150 to +350
Denitrification	-50 to +50
Polyphosphate release	-40 to -175
Acid formation	-40 to -200
Sulfide formation	-50 to -250
Methane formation	-200 to -400

Courtesy of WET



Courtesy of Hach

Total Suspended Solids

- Many Optical Instruments (Visible/ Near-IR) on the Market
- Typically In-situ, bypass available
- Ensure Correct Measuring Range is Selected (Pathlength)



Courtesy of InsiteIG



Courtesy of Hach

Flow

- Different types of flow measurement devices
- Different devices are suitable for different types of installations
- Always consider the end use of the data (e.g. chemical pacing, simple trending, regulatory reporting)



Courtesy of Rosemont



Courtesy of Siemens

Ammonia

- In-situ ISE Probes
 - Accuracy/performance varies
 - Require calibration
 - Replacement of electrodes
- Cabinet-type analyzers
 - Accurate
 - Sample filtration and delivery challenging in WWTPs
 - Consumables replacement



Courtesy of WTW



Courtesy of ChemScan

Nitrate (Nitrite?)

- In-situ ISE Probes
 - Many MFRs performance varies
 - Often coupled with ammonia ISE
 - Calibration/replacement of electrodes
- In-situ UV
 - Utilizes absorbance from 200 – 220 nm
 - Many MFRs
 - Low O&M requirements/costs
- Cabinet-Type Analyzer
 - Pump/filter
 - Reagents
 - Accurate



Image Courtesy of WTW



Image Courtesy of s::can

Phosphorous

- Cabinet-Type Analyzer
 - Pump/filter
 - Reagents
 - Accurate
 - Many MFRs, costs vary




Courtesy of ChemScan

Case Study #1


Energy and Chemical Savings
Through Ammonia-Based DO
Control

Case Study #1 – Background

- Ammonia-based DO control
- Modeled potential savings in energy/chemical




Case Study #1 – Background




Case Study #1 – Background

- Operator selects effluent ammonia setpoint
- Ammonia > setpoint, DO increased
- Ammonia < setpoint, DO decreased



Case Study #1 – Background




Case Study #1 – Process Model

- Process modeling concluded that process air (6%) and carbon (20%) savings were possible using an ammonia-based DO control scheme

Date	DO Setpoint Control		DO/NH3 Control	
	Total Nitrogen (Effluent)	Avg Daily SCFM	Total Nitrogen (Effluent)	Avg Daily SCFM
7/1/2013	10.6	10,400	10.6	9,900
7/2/2013	10.3	10,300	10.0	9,600
7/3/2013	10.0	10,300	9.8	9,800
7/4/2013	7.8	9,500	7.4	8,800
7/5/2013	12.2	11,500	12.4	10,800
7/6/2013	6.3	9,500	6.0	8,700
7/7/2013	8.1	10,900	8.4	10,400
Average	9.3	10,300	9.2	9,700

Case Study #1 – Process Model

- The ammonia-based DO control scheme relies on accurate ammonia measurement below 1 mg/L (NH₃-N)




Case Study #1 – Implementation


- The ammonia sensors located on site were evaluated and could not measure below 1 mg/L with consistent accuracy.
- When automated operations using the ammonia sensors were attempted, process upsets resulted (loss of nitrification)
- ***The sensors must be reliable at the level needed for enhanced control***

Case Study #1 – Details


- If $\text{NH}_3\text{-N} < 0.75 \text{ mg/L}$
 - DO setpoint in Zone 2, 3 and 4 = 0.3 mg/L
- If $\text{NH}_3\text{-N} > 1.0 \text{ mg/L}$
 - DO setpoint in Zone 2, 3 and 4 = 2.0 mg/L



Case Study #1 – Details



Case Study #1 – Details



Case Study #1 – Next Steps

Load-based Ammonia Equalization Program

Setpoint	2000 LB/D
Actual	2200 LB/D
Flow into EQ	0.86 MGD
Flow out of EQ	0 MGD
EQ Level	60%

Clarifier Optimization Program



Solids Loading Rate
(lb/d/ft)

2

No. Clarifiers
Required



SVI

Bio P Monitoring Program

Aerobic HRT	4 HOURS
Effluent Ortho.	0.1 MG/L
Alum Use	50 GPD
Trend	Stable Up Down

Nitrification Monitoring Program



Aerobic SRT, days

Nitrification Troubleshooting Program

Basin Effluent Ammonia
Lab Ammonia
Run Troubleshooting Prog.

0.1 MG/L
0.1 MG/L
NOT NEEDED

Denitrification Optimization Program



BOD: Ammonia Ratio



Internal Recycle Pump Rate



Carbon Feed: Gal/Day

0.1 MG/L

Effluent Nitrate

Case Study #2


Optimizing Carbon Dosing

Case Study #2 – Background

- Five (5) WWTPs where supplemental carbon added to enhance denitrification
- Utilization of nitrate instrumentation to optimize carbon addition rate
- Evaluated different sensor locations and control schemes to determine best ROI (BioWin)


Case Study #2 - Background

- NH₃-N load varies significantly throughout the day
- COD/NH₃-N ratio also varies throughout the day




Case Study #2 – Dosing Strategy 1

- Flow-paced carbon addition based on influent flow rate




Case Study #2 – Dosing Strategy 2

1. Mass-paced carbon addition based on ratio of COD to Nitrate/Nitrite entering the head of Pass D



Case Study #2 – Dosing Strategy 3

- Feedback trim based on the Nitrate/Nitrite concentration at the end of the Pass D anoxic zone



Case Study #2 – Summary of Results

- Plant A shows that the more sophisticated strategy results in greater savings

	Strategy 1		Strategy 2		Strategy 3		% Carbon Savings over Strategy 1	
	Eff TN	Carbon	Eff TN	Carbon	Eff TN	Carbon	Strategy 2	Strategy 3
	mg/L	gpd	mg/L	gpd	mg/L	gpd		
Plant A	8.9	6,620	8.8	6,270	8.9	5,870	5.3%	11.4%
Plant B	6.8	2,190	6.8	1,940	n/a		11.3%	n/a
Plant C	8.3	7,910	8.2	7,850	n/a		0.8%	n/a
Plant D	5.2	820	5.2	760	n/a		7.6%	n/a
Plant E	5.9	4,090	6.0	3,910	n/a		4.3%	n/a

Conclusions

- Instrumentation has clear benefits for advanced WWTP processes
- Understanding goals and considerations up front is essential for success
- Process modeling can help understand the concrete benefits of a control scheme and help the decision-making process

Questions?



HAZEN AND SAWYER
Environmental Engineers & Scientists